



How to change rear
shock absorbers on
Peugeot 208 1 –
replacement guide

VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

PEUGEOT 208 I Hatchback (CA_, CC_) 1.6, PEUGEOT 208 I Hatchback (CA_, CC_) 1.4 HDi, PEUGEOT 208 I Hatchback (CA_, CC_) 1.6 HDi, PEUGEOT 207 Saloon 1.4, PEUGEOT 207 Hatchback 1.4, PEUGEOT 207 Hatchback 1.4 16V, PEUGEOT 208 I Hatchback (CA_, CC_) 1.0, PEUGEOT 208 I Hatchback (CA_, CC_) 1.4 VTi, PEUGEOT 208 I Hatchback (CA_, CC_) 1.6 GTi, PEUGEOT 208 I Hatchback (CA_, CC_) 1.2 THP, PEUGEOT 208 I Hatchback (CA_, CC_) 1.6 HDi / BlueHDi 75, PEUGEOT 208 I Hatchback (CA_, CC_) 1.6 BlueHDi 120, PEUGEOT 208 I Hatchback (CA_, CC_) 1.4 GPL, PEUGEOT 208 I Hatchback (CA_, CC_) 1.2 GPL, PEUGEOT 208 I Hatchback (CA_, CC_) 1.2

The steps may slightly vary depending on the car design.

REPLACEMENT: SHOCK ABSORBERS – PEUGEOT 208 1. TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Drive socket # E18
- Drive socket # 16
- Torx bit T20
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Ear clamp pliers
- Hydraulic transmission jack
- Wheel chock

[BUY TOOLS](#)

Replacement: shock absorbers – Peugeot 208 1. AUTODOC experts recommend:

- Both shock absorbers of the rear suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right shock absorbers of the rear suspension.
- All work should be done with the engine stopped.

REPLACEMENT: SHOCK ABSORBERS – PEUGEOT 208 1. USE THE FOLLOWING PROCEDURE:

1

Secure the wheels with chocks.



2

Loosen the wheel mounting bolts. Use wheel impact socket #17.



3

Raise the rear of the car and secure on supports.



4

Unscrew the wheel bolts.



Replacement: shock absorbers – Peugeot 208 1. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.


5

Remove the wheel.




6.1

Unscrew and remove the wheel arch cover fasteners.



6.2

Use Torx T20. Use ear clamp pliers.




7 Remove the wheel arch cover.




8 Detach the fastener of the rear axle plastic protecting cover.




9 Support the rear suspension beam. Use a hydraulic transmission jack.



10.1 Clean the shock absorber fasteners.




10.2 Use a wire brush. Use WD-40 spray.



11

Unscrew the upper fastener of the shock absorber. Use a drive socket #16. Use a ratchet wrench.




12

Remove the fastening bolt.




13

Unscrew the lower fastener of the shock absorber. Use a drive socket #E18. Use a ratchet wrench.



14


Remove the fastening bolt.



AUTODOC recommends:

- Important! Hold the shock absorber while unscrewing the fastening bolts.
Peugeot 208 1

15 Remove the shock absorber.




16 Treat the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.




Replacement: shock absorbers – Peugeot 208 1. AUTODOC experts recommend:

- Before installing a new shock absorber you should pump it manually 3-5 times.

17 Place the shock absorber in the wheel arch and fasten it.



18 Install the fastening bolts.




AUTODOC recommends:

- Peugeot 208 1 – To avoid injury, hold the shock absorber while screwing in the fastening bolts.

19

Tighten the top shock absorber fastening. Use a drive socket #16. Use a torque wrench. Tighten it to 60 Nm torque.




20

Tighten the lower fastener of the shock absorber. Use a drive socket #E18. Use a torque wrench. Tighten it to 100 Nm torque.



21


Remove the mounting from under the rear axle beam.




Replacement: shock absorbers – Peugeot 208 1. AUTODOC recommends:

- Lower the hydraulic transmission jack smoothly, without jerks, to avoid damaging assemblies and mechanisms.


- 22 Treat the shock absorber fasteners. Use copper grease.




- 23 Install the wheel arch cover to its mounting seat.




- 24 Install and tighten the wheel arch cover fasteners. Use Torx T20.



- 25 Install the rear axle plastic protecting cover and fasten it.



- 26 Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



27

Install the wheel.



Replacement: shock absorbers – Peugeot 208 1. Professionals recommend:

- To avoid injury, hold up the wheel when screwing in the fastening bolts.

28

Screw in the wheel bolts. Use wheel impact socket #17.



29

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 100 Nm torque.



30

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
 Google Play

 Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR PEUGEOT

SHOCK ABSORBERS: A WIDE SELECTION

CHOOSE CAR PARTS FOR PEUGEOT 208 1

SHOCK ABSORBERS FOR PEUGEOT: BUY NOW

**SHOCK ABSORBERS FOR PEUGEOT 208 1: THE BEST DEALS
& OFFERS**

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2022 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.